OZZ XB18"

88204 (black)

Before installation

- 1. Check the locallaws and regulations and the region your vehicle may travel to for LED Light Bar before installation, ensure they are compliance.
- 2. Read all installation instructions.
- 3. Make sure the dimension and weight of the lamps and device are matched to your vehicle, see figure 01.
- 4. Slight moisture inside may exist, it will be removed out from the vent after 2-4 time working.
- 5. Working Voltage: 10-32V DC.

Mounting

- 1. Drill 8.5mm holes for screw placement on the surface where you would like to fix the light.
- 2. Use the bolt to fasten the lamp, add the locking washer and tighten the bolt.
- 3. Illustration of multi mounting options: side bracket and bottom bracket.

Wiring connections & Functions

1. Wiring connections

Black: Ground,-Red: Driving beam,+ Blue: Reflector dynamic,+

2. Wiring Harness, 40A relay, 30A fuse.

Figure 01





